



#### **A2 SGS Spark Gap Setter**

*For setting the output voltage of Spark Testers i.e. PST100, ST-AC 100, C200K Mk5 and PPM Mk3*

*Note: Not recommended for use with TMF Spark Testers*



#### **A4 Adaptor**

*Used to connect straight Phosphor Bronze Electrodes (E104 - E124) or straight Silicone Rubber Electrodes (E204 - E224) direct to test probe handle*



#### **Insulated Extension Rods**

**A7** 220mm long **A8** 330mm long **A11** 460mm long **A9** 1000mm long



#### **A12 Shoe Attachment**

*Connects Rolling Spring Electrodes (E704 - E748) to an extension rod, can also be used to connect straight Phosphor Bronze (E104 - E124) or straight Silicone Rubber Electrodes (E204 - E224). Note: Only suitable for DC equipment.*



#### **A13 Earthing Magnet**

*For making an Earth connection on smooth surfaces*

**OTHER ACCESSORIES ARE AVAILABLE INCLUDING CARRYING CASES, EARTH LEADS & TEST PROBE HANDLES**

Note: Due to ongoing technical developments, all stated information is typical and is subject to change without notice or obligation

### **AFTER SALES SERVICE / TECHNICAL SUPPORT**

All Buckleys products are manufactured under the controls established by a quality management system that meets the requirements of BS EN ISO 9001:2008 and are supplied with a one year "back-to-base" warranty. The equipment is proven to be robust and reliable and will give years of service if maintained in accordance with our instructions.

Distributed by:

Interprovincial Corrosion Control Co. Ltd.

930 Sheldon Court

Burlington, Ontario L7L 5K6

Telephone: (905) 634 7751

Fax: (905) 333 4313

Website: [www.Rustrol.com](http://www.Rustrol.com)